



NOTE: USE TAPERED ROOF INSULATION (EDGE STRIPS) TO CREATE DRAIN SUMP. IF TOTAL INSULATION THICKNESS IS LESS THAN OR EQUAL TO 1 1/2 IN., TAPER 12 IN. FROM THE DRAIN CENTER. IF TOTAL INSULATION THICKNESS IS GREATER THAN 1 1/2 IN., TAPER 18 IN. FROM DRAIN CENTER.



GENERAL REFERENCE: <b>"FTR GS06"</b>		
APPLICABLE SYSTEMS: <b>"FTR MA06"</b> <b>"FTR AD06"</b> <b>"FTR BA06"</b>		
<b>TYPICAL DRAIN FLASHING</b>		
REVISES DETAIL	ISSUE DATE	DRAWING NUMBER
<b>ALL PREVIOUS</b>	<b>03-01-07</b>	<b>FTR-DD1</b>